



## LABORATORY HORIZONTAL AUTOCLAVE

BE01F5


# INDEX

1. Safe Operation Specifications	2
2. Main maintenance tools	3
3. Maintenance method of alarm fault code of control panel	4
4. Common fault maintenance	12
5. Description of instrument components	13
6. Replacement Methods of Main Parts	15
7. List of Common Accessorie	28

# 1. Safe Operation Specifications

1. Before maintenance, anti-static work should be done first. For example, wear anti-static work clothes, shoes and rubber gloves, and do not operate with wet hands to avoid electric shock and short circuit damage to parts;
2. Any electrical equipment and lines shall be deemed to be electrified and shall not be touched until they have been verified by themselves. When they need to be contacted, the power supply shall be cut off. After experiencing electricity and discharge (capacitive facilities), the electrical equipment shall be used to test whether they are electrified. Only after it is confirmed that they are not electrified can inspection and repair be carried out. During the electrical inspection, special electrical equipment shall be used and the measuring gear shall be adjusted to the appropriate gear. Before the electrical inspection, the test shall be carried out on the electrical equipment Determine whether the electrical testing equipment is in good condition. During the high-voltage electrical testing, insulating gloves must be worn, and it is forbidden to test with hands;
3. When it is necessary to contact strong electricity, pay attention to personal safety and take anti-electricity measures;
4. It is not allowed to disassemble and repair the instrument during its operation. It must wait until the instrument stops running and cut off the main power supply and water source of the instrument. When there is no pressure in the chamber, the evaporator shall drain water and stand for more than 3 hours. After the instrument is completely cooled, disassemble and repair it according to the safe operation procedures;
5. All wires and power terminals of electrical equipment that are temporarily removed must be wrapped with insulating tape, and no exposed parts are allowed. Power lines and pipes that are no longer used shall be removed;
6. The connectors of various electrical wiring shall ensure continuity, the wiring shall not be loose, the wire ends shall not protrude, and the insulation binding shall meet the requirements, and shall be neat and beautiful;
7. The tester shall not change the original structure and wiring mode of the instrument without the permission and approval of the electrical technical director of the headquarters;
8. After each maintenance, check whether the lines are connected incorrectly, and whether there are materials, spare parts, tools and other items left in the electrical lines and electrical equipment to prevent accidents caused by loss in the equipment. Power on after confirmation;
9. After power-on, pay attention to observe at any time to see if there is any abnormal sound, peculiar smell and action. If there is any abnormal phenomenon, turn off the power immediately to stop the operation of the instrument to avoid causing more serious accidents;
10. In case of fire in electrical equipment, cut off the power supply immediately, use carbon dioxide dry powder fire extinguisher or carbon tetroxide dry powder fire extinguisher, and do not use water to put out the fire;

## 2. Main maintenance tools

			
Cross screwdriver	Cross screwdriver	Cross screwdriver	inner hexagon spanner

			
Diagonal pliers	Open-end wrench	Adjustable wrench	Electric soldering iron and soldering tin
			
Sleeve	A multimeter	PTFE TAPE	Electrical tape
			
Electric drill	Needle nose pliers	Hot melt gun	75mm and 50mm Open-end wrench

# 3. Maintenance method of alarm fault code of control panel

## 1. Fault code directory

E0 1	E0 2	E0 3	E0 4	E0 6	E1 0
E1 1	E1 2	E1 6	E1 9	E2 1	E2 2
E2 3	E2 4	E2 6	E2 8	E3 6	E4 3
E4 6					

## 2. Maintenance method of fault code displayed on control pane

Fault code	Fault description	Possible causes	Exclusion method	remarks
code E01	After starting the sterilization chamber door is not locked or the chamber door interlock fails;	The cover is not closed in place and the cavity cover is not closed tightly during the user's use; The microswitch in the cavity cover is not actually stuck in place, or the microswitch is damaged;	Check that the indicator of the lid lock on the LCD screen flashes red, and then close the lid again; Remove the outer cover of the chamber, check the conduction of the microswitch when closing the door, and adjust the position of the microswitch;	real- time detectio n
		3.The fuse of the interlocking motor is burnt or the motor is damaged; 4.The intermediate relay controlled by the corresponding interlocking motor is burnt	3. When opening the door, check whether the interlocking motor terminal is normally powered by AC220V, check whether the fuse is damaged and replace it;	
		5. The wiring of the corresponding motor power supply circuit falls off, loosens, heats up and burns	4. Check whether the intermediate relay coil is closed normally;	
		6. The corresponding output point of the control motor on the PLC or the corresponding input point of the microswitch is damaged;	5. Check whether the wiring from the power incoming line to the two main contacts of the intermediate relay and from the contactor to the terminal is good	

			6. Check whether the corresponding output point of PLC is on, and	
			whether the input point inputs the ON signal, otherwise	
code E02	After starting the procedure, no change of evaporator temperature is detected within a certain period of heating	Solid state relay fault; Heating pipe failure; Heating contactor fault; PLC output point fault	Observe whether the solid-state relay indicator flashes green normally, otherwise, the next step; Measure whether the resistance of each two wires of the heating pipe is about 10.2 Ω, otherwise replace the heating pipe; Check whether the input and output voltage of the contactor are normal, or replace the contactor; Check whether the corresponding output voltage of PLC is within DC24V, or replace the PLC module;	real- time detectio n
code E03	After starting the program, it is detected that the normally closed signal of temperature control switch and pressure	The temperature start value of the temperature control switch is not adjusted to about 260 °, or the temperature control switch is damaged; Pressure switch failure; The input points of	Check whether the temperature of the temperature control switch is set accurately and rotate it for adjustment; Check and measure whether the voltage at both ends of temperature control and pressure switch is normal	real- time detectio n
	switch becomes normally open;	temperature control and pressure switch controlled by PLC are damaged; 4. The temperature control switch is actually started, there is no water in the cavity, and the reason for pure water inlet valve, pipeline and pressure	and whether there is normal voltage. If yes, replace the temperature control switch and pressure switch; 3. Check whether the PLC input port is in the ON state, and if so, how to replace the PLC module; 4. Check whether the pure water is open, whether the pipeline is damaged by water leakage, and whether the pressure is normal;	

code E04	<p>① : The temperature in standby is greater than the maximum working temperature set in the background;</p> <p>② : The chamber temperature is greater than or less than the sterilization temperature limit value during sterilization;</p>	<p>Poor contact of temperature sensor or corresponding terminal of PLC;</p> <p>The sterilization process is reported to E04, mainly to confirm whether the cold air is discharged normally, whether the sterilization articles are sealed, and whether the instrument is leaking;</p> <p>If E04 fails to enter the sterilization stage during the heating process, the temperature compensation value of the inner chamber is usually insufficient, and the temperature and pressure cannot correspond</p>	<p>Check and lock the temperature sensor terminal wire, or replace the temperature sensor;</p> <p>Check whether the sterilization items and status are normal, run an empty process again, and compare whether there is a fault code;</p> <p>Check whether the cavity temperature display value is normal during no-load operation, or reset the inner chamber temperature compensation in the advanced parameters;</p>	real- time detectio n
code E06/07	<p>E06 The judgment condition is that the temperature sensor is open</p> <p>E07 judges that the condition is that the temperature sensor is short-circuited</p>	<p>The sensor is broken, or the wiring is loose or the contact is poor;</p> <p>The temperature port corresponding to PLC is broken, replace or repair the main board;</p>	<p>Check whether the terminal can be removed normally by replacing it with 120 Ω resistance (equivalent to 50 °C); If it is normal, the sensor is broken;</p> <p>2. Replace the original position sensor with 120 Ω. If it cannot work normally, replace the PLC temperature module;</p>	real- time detectio n
code E10	Abnormal interruption of sterilization process	<p>The sterilization is not completed and the trip is interrupted;</p> <p>The sterilization is not completed and the power is cut off artificially;</p>	<p>Check whether the current is overloaded and restart sterilization;</p> <p>Press the confirmation key to remove the code and restart sterilization;</p>	real-time detection

code E11	Abnormal water inflow;	The pure water inlet pipe and valve are not opened, and the water supply is abnormal; Whether the pure water pressure meets the pressure of 0.1-0.5MPa; The liquid level switch is damaged or dirty; Whether the input and output points corresponding to PLC are	Check whether the water inlet of the pure water pipeline is normal and whether the valve is open; Check whether the booster pump works normally and whether the pressure is normal; Check whether the liquid level switch is damaged and whether the inner wall is dirty, disassemble and clean it;	real-time detection
		damaged	4. Check whether the PLC booster pump is damaged and whether the input of the PLC level switch is normal	
code E12	① : When the sterilization process is over and the temperature is lower than the cover opening temperature, the diaphragm switch is not closed (the top rod of the diaphragm switch does not fall off); ② : During the heating process, when the main control temperature is greater than the pull-in action temperature, the micro-pressure switch is still in the pull-in state (the top rod of the diaphragm switch is not pushed up)	If the E12 fault is reported during the heating process, confirm whether the pressure gauge shows that the pressure has reached 0.015MPa at 110 °C, and if it does not indicate that the temperature and pressure are not corresponding; If E12 fault occurs after sterilization; E12 will be reported immediately after startup and cannot be cancelled; When the temperature drops to the point where the cover cannot be opened, E12 will be reported;	The diaphragm switch is usually replaced; Start up and report E12. Use a multimeter to detect that the PLC has 24V output, which usually means that the connecting wire or diaphragm switch is broken. If there is no output, the PLC is broken; Pull the safety valve to see if there is pressure in the cavity. If yes, continue to pull the safety valve to relieve pressure. Otherwise, replace the diaphragm switch	real-time detection
code E16	E16 judges that the condition is that the article temperature sensor is open	The temperature sensor of the article is broken or has poor contact;	Check whether the terminal can be removed normally by replacing it with 120 Ω resistance; If it is eliminated normally, the sensor is broken;	real-time detection
	E17 judges that the condition is that the article temperature sensor is short-circuited	2. The temperature port corresponding to the main board is broken, replace or repair the main board;	2. Replace the original position sensor with 120 Ω. If the fault cannot be eliminated, replace the PLC or PLC for repair;	

code E19	It is judged that the container level sensor is dirty	The liquid level sensor is dirty; PLC input point is damaged;	Remove the liquid level switch and clean it; Replace the PLC input point module;	real-time detection
code E21	Vacuum leakage fault: keep vacuuming, pressure does not drop	The instrument detects a leak: Check whether the sealing ring, solenoid valve, copper pipe joint and other positions of the instrument are leaking; The sealed cavity tube and sterilization bag of the instrument are loaded too much, and the air cannot be completely discharged by vacuuming; The vacuum pump does not work, the voltage supply is out of phase	Replace the heating or solenoid valve; Take out the load and compare it with no-load operation; Check the power supply of vacuum pump and run again;	real-time detection
code E22	Vacuum leakage fault: during the vacuum test, the cavity pressure increases too much in the first 5 minutes	During vacuum leak test: Check whether the sealing ring, solenoid valve, copper pipe joint and other positions of the instrument are leaking; The sealed cavity tube and sterilization bag of the instrument are loaded too much, and the air cannot be completely discharged by vacuuming;	Replace the heating or solenoid valve; Take out the load and compare it with no-load operation; Check the power supply of vacuum pump and run again;	real-time detection
code E23	Vacuum leakage fault: during sterilization, the cavity pressure is not within the range of saturation pressure ( $\pm 27\text{kPa}$ )	At sterilization stage: The pressure and temperature values do not correspond, usually the pressure or temperature compensation value is incorrect, and the compensation value shall be compared and set again during no-load operation; The sealed cavity tube and sterilization bag of the	Reset the compensation value during no-load operation; If there is water in the chamber, the steam will not be saturated. Open the drain valve; Check whether the sterilization articles are loaded too much and whether the sealed sterilization bag is open;	real-time detection
		instrument are loaded too much, and the air cannot be completely discharged by vacuuming;		

code E24	During the test of the safety valve in the chamber, the pressure relief value of the safety valve is reached after the pressure is increased, and the pressure relief of the safety valve is not detected;	The safety valve pipeline is blocked; Safety valve failure;	Check and clean the safety valve pipeline; Replace the safety valve;	real-time detection
code E26/27	E26 judges that the condition is that the inner chamber pressure sensor is open E27 judges that the condition is short circuit of inner chamber pressure sensor	The pressure sensor is broken or has poor contact; The corresponding pressure port of PLC is broken, replace or repair the PLC;	Check the PLC terminal and use a multimeter to measure whether there is DC24V. If yes, the pressure sensor is broken; Check the PLC terminal and use a multimeter to measure whether there is DC24V. If there is no DC24V, replace the PLC for repair;	real-time detection
code E28	Fault judgment conditions: ①: When the interlocking motor is not running, the interlocking in-place microswitch and the interlocking release in-place microswitch are detected to be connected at the same time; ②: When the interlock motor is	The interlock in place microswitch is damaged; Interlocking motor is stuck and does not operate;	Check whether the manual interlock in place switch and interlock release in place switch are normal, or replace the microswitch; Check whether the motor can rotate normally, or replace the interlocking	real-time detection
	started, it is not detected that the interlock in place microswitch is connected for a certain time; ③: The interlocking motor has not detected that the interlocking release in place microswitch is connected for a certain time at the beginning;	3. Motor power supply line fault, PLC damage;	motor; 3. Check whether the PLC does not normally output 24V to the relay when opening or closing the cover interlock action, replace or repair the PLC, and the circuit does not supply 220V voltage to the motor, then check whether the circuit is abnormal	

code E36	Optional: water source pressure sensor fault;	The tap water pressure is insufficient, check whether the water pressure is normal; Water source pressure sensor fault; The corresponding pressure port of PLC is damaged	Check whether the water source valve is open and whether the pressure is normal; Replace the water source pressure sensor; Replace or repair the corresponding port or module of PLC	real-time detection
code E43	Fault judgment condition: door opening and closing interlock system fault	The interlock motor is on, and the microswitch action of the open position is not detected; The door lock motor is opened, and the door pin microswitch action is not detected; The interlock motor is on, and the microswitch action of closing in place is not detected	The microswitch is damaged or not adjusted in place; The motor is stuck or damaged;	real-time detection
code E46	Fault judgment conditions: Evaporator pressure sensor fault; Open/short circuit Sandwich pressure sensor failure; Open/short circuit	The pressure sensor is broken or has poor contact; The corresponding pressure port of PLC is broken, replace or repair the PLC;	Check the PLC terminal and use a multimeter to measure whether there is DC24V. If yes, the pressure sensor is broken; Check the PLC terminal and use a multimeter to measure whether there is DC24V. If there is no DC24V, replace the PLC for repair;	

## 4. Common fault maintenance

### 1. No power on

Check whether the main power supply of the instrument is connected, whether the emergency stop interlock device is released, and whether the interlock key is released;






Figure 1

Step 1 Check whether the power supply is normal

Step 2 Check whether the instrument circuit breaker is powered on

Step 3 Check whether the emergency stop button is released and whether the interlock key is opened (AC gear of multimeter measures 380V three-phase power supply) (AC gear of multimeter measures) (manual rotation)

B. Check whether the power supply of the instrument LCD is normal, and whether the buzzer is normal to prompt whether the plug between the startup and PLC is properly plugged in;



Figure 2



Figure 3

Step 1 Check whether the patch cord on the PLC falls off

Step 2 Check whether the plug wire on the back of the LCD screen falls off and whether the DC24V power supply terminal is loose

# 5. Description of instrument components




Figure 4  
Front view




Figure 5  
Dorsal view




Figure 6

## 6. Replacement Methods of Main Parts

Before replacing parts, power off and close the water inlet valve to release the pressure in the inner chamber and evaporator, and drain the water in the evaporator at the same time. The instrument should be left standing for more than 3 hours:



Figure 7

Step 1. Turn the interlocking key to turn off the power and press the emergency stop button



Figure 8

Step 2. Disconnect the circuit breaker of the instrument



Figure 9

Step 3. Disconnect the power supply of the wall instrument and pull out the aviation plug




Figure 10

Step 4. Turn off the water supply of the instrument so that the instrument does not enter water (Close the water supply valve of the instrument)




Figure 11

Step 5. Confirm that there is no pressure in the chamber (if there is, pressure relief is required)



Figure 12

Step 6. Evaporator pressure relief

(Use a long metal rod or screwdriver to lift and pull the safety valve to relieve pressure, and pay attention to prevent scalding by steam)



Figure 13

Step 7 Inner chamber pressure relief



Figure 14

Step 8. Open the evaporator drain outlet and drain the evaporator water

(Use a long metal rod or screwdriver to lift and pull the safety valve to relieve pressure, and pay attention to prevent scalding by steam) (Note: after maintenance, check that the valve must be closed before operation)



Figure 15  
Step 9 Press the handle



Figure 16  
Step 10. Lift up the handle and remove the door panel  
(The removal method of left and right rear door panels is the same)

### 1. Replacement of sealing ring



Figure 17  
Step 1. Take out the seal ring as shown in the figure




Figure 18

Step 2. Put on a new sealing ring (the whole ring is clamped into the groove in 4 equal sections, and the position with small holes is upward)



Figure 19

Step 3. Press the sealing ring edge flush



Figure 20

Step 4. Check whether the whole sealing ring is flush with the edge (it must be flush or there will be air leakage)

## 2. Replacement of pressure gauge



Figure 21

Step 1. Remove the copper pipe joint (25 # wrench fixed end seat, 18 # wrench nut)



Figure 22

Step 2. Remove the clip and pressure gauge  
(Unscrew the nut with a 12 # wrench and the clip with a small cross screwdriver)



Figure 23

Step 4. Screw the connector of the new pressure gauge (25 # wrench fixed end seat, 18 # wrench nut)



Figure 24

Step 4. Install a new pressure gauge and connect the copper pipe  
(keep the front side upright) (Unscrew the nut with a 12 # wrench and the clip with a small cross screwdriver)

### 3. Replacement of safety valve

#### A. Installation of inner chamber safety valve




Figure 25  
Step 1. Loosen the safety valve nut



Figure 26  
Step 2. Remove the safety valve (wrap the raw material belt)  
(Pay attention to the position of the bottom nut with the 17 # wrench, otherwise the safety valve will be damaged)



Figure 27  
Step 3. Screw on the new safety valve (Unscrew the nut with 17 # wrench)



Figure 28  
Step 4. Tighten the fixing screws of the safety valve (Turn the bottom nut with No. 7 wrench)

## B. Installation of evaporator safety valve



Figure 29

Step 1. Loosen the retaining nut of the safety valve



Figure 30

Step 2. Unscrew and remove the safety valve (wrap the raw material belt) (22 # wrench to fix the lower end seat, 17 # wrench to screw the middle nut)



Figure 31

Step 3. Wrap the raw material belt



Figure 32

Step 2. Install the safety valve, tighten the safety valve, and screw down the screw to fix the safety valve (22 # wrench to fix the lower end seat, 17 # wrench to screw the middle nut)

#### 4. Replacement of solenoid valve




Figure 33

Step 1. Loosen the solenoid valve terminal valve (with a cross screwdriver)



Figure 34

Step 2. Unscrew the copper pipe connector and remove the exhaust solenoid (No. 18 wrench turns the nut and No. 25 wrench fixes it)



Figure 35

Step 3. Connect the copper pipe connector of the new solenoid valve (No. 18 wrench turns the nut and No. 25 wrench fixes it)



Figure 36

Step 4. Reinstall the solenoid valve and terminal (pay attention to the sealing ring of the stainless steel pipe) (Cross screwdriver, pay attention to the positive and negative wiring and ground wire, and connect them according to the original wiring method)

#### 5. Replacement of heating pipe




Figure 37

Step 1. Remove the three terminal wires of the heating tube




Figure 38

Step 2. Remove the temperature control switch (Mark must be made, and the wiring of new heating pipe cannot be wrong) (75mm and 50mm wrench)



Figure 39

Step 3. Loosen the nut inside the chamber and take out the heating pipe



Figure 40

Step 4. Wrap the new heating tube with raw material tape and clamp the tem control switch probe at the end of the heating tube



Figure 41

Step 5. Mark the probe height of the new heating tube temperature control switch upward



Figure 42

Step 6. Put in a new heating tube (the heating tube must be wrapped with raw material tape)



Figure 43

Step 7. Rotate and fix the new heating tube (the marked position is upward)



Figure 44

Step 8. Reinstall the temp control switch (Note that the scale of the temperature control switch chassis faces to the left and the temperature is adjusted to 250)



Figure 45

Step 9. Connect the heating pipe wire (note that the wire must be connected in the original way and cannot be connected incorrectly)



Figure 50

Step 10. Check that the wiring is normal, then run the test machine

## 6. PLC replacement




Figure 51

Step 1. Loosen the wiring block of PLC upper and lower ports



Figure 52

Step 2. Open the plug cover and unplug the plug cable between PLC and expansion module



Figure 53

Step 3. Remove the PLC and unscrew the power supply terminal of the PLC;




Figure 54

Step 4. Install the new PLC and power supply terminals according to the original connection method, and turn back the terminal block in turn;

## 7. List of Common Accessorie

Serial no.	Picture	Description
1	PLC The original machine photo and software version number are required to order PLC accessories	
2	circuit breaker	
3	Pressure switch	
4	temp control switch	

5	Solid-state relay	
6	KM1 contactor	
7	Solenoid valve	
8	Interlocking motor	
9	seal ring	

10	pressure gage	
11	Safety valve	
12	Heating pipe	



Biolab Scientific Ltd.

Trillium Executive Center, East Tower, 675 Cochrane Dr, Markham, Ontario L3R 0B8, Canada  
Email: [info@biolabscientific.com](mailto:info@biolabscientific.com) | Website: [www.biolabscientific.com](http://www.biolabscientific.com)