



## GENERAL PURPOSE INCUBATOR

BER-1802

# INDEX

1. Safety warning before use	2
2. Main features of product	3
3. Technical Specification	4
4. The panel indication	5
5. Operations and usages	7
6. Seven The internal parameters of the temperature are seen and Set.	9

# 1. Safety warning before use

1. Do not store volatile, flammable or explosive materials in the equipment, otherwise it may cause explosion or fire.
2. Do not place the equipment in a place that is wet, wet or may splash water, otherwise it may lead to accidents such as leakage, short circuit or electric shock.
3. Non-professional technicians shall not disassemble, repair or modify the equipment, otherwise it may cause fire or electric shock accidents due to improper operation.
4. The equipment should be installed on a solid ground. If the ground is not solid enough or the installation site is not suitable, injuries may be caused by the equipment tipping over.
5. The equipment should be installed on a solid ground. If the ground is not solid enough or the installation site is not suitable, injuries may be caused by the equipment tipping over.
6. Before any repair or maintenance of the equipment, be sure to disconnect the power supply to prevent electric shock or personal injury.
7. Be sure to wear gloves when performing equipment repair or maintenance to prevent injury caused by touching edges or sharp corners.
8. If the equipment is found abnormal operation, immediately unplug the power plug, stop the operation of the equipment. Operation under abnormal conditions may cause electric shock or fire.

# 2. Main features of product

- 1, the use of intelligent PID temperature controller table with timing, alarm indication, temperature deviation correction, temperature control self-tuning and other functions, temperature control accurate and stable.
  - 2, with over temperature power off, alarm indicating system, when the control temperature exceeds the set upper limit instrument automatically cut off the power output buzzer alarm. Ensure the safety of experiment and personnel.
  - 3, the integrated liner structure is simple and beautiful, the magnetic tape seal and the training door lock device is safe and convenient to use.
  - 4, the four walls around the heating to ensure that the internal temperature is uniform.
  - 5, good thermal insulation design, prevent the ability to lose too fast, the maximum extent to achieve green, energy saving, low carbon environmental protection.
  6. The box shell is treated by electrostatic spraying process, beautiful and generous in shape, anti-corrosive and durable, showing the luxurious and elegant instrument shape.
- \* Portable box design portable convenient for outdoor emergency, vehicle transport and other venues.

### 3. Technical Specification

Model		BER-1801	BER-1802
Cycle Mode		Natural convection	
Function	Temp. Range	RT+5-65°C	
	Temp. Resolution Ratio	0.1°C	
	Temp. Motion	±0.5°C	
	Temp. Uniformity	±1.5°C	
Structure	Inner Chamber	Mirror stainless steel	
	Outer Shell	Cold rolling steel electrostatic spraying exterior	
	Insulation layer	Polyurethane	
	Heater	Heating Wire	
	Power Rating	0.08kW	0.12kW
Controller	Temp. control mode	PID Intelligent	
	Temp. setting mode	Touch button setting	
	Temp. display mode	Measuring temperature: LED upper row;Setting temperature: the lower row	
	Timer	0-9999min (with timing wait function)	
	Operation function	Fixed temperature operation, timing function,auto stop.	
	Additional function	Sensor deviation correction, temperature overshoot self-tuning, internal parameter locking, power-off parameter memory	
	Sensor	PT100	
Safety device		Over temperature sound-light alarm	
Specification	Inner Chamber size(W*L*H)(mm)	230*200*200	230*200*280
	Exterior size (W*L*H)(mm)	310*276*298	310*276*378
	Packing size (W*L*H)(mm)	350*312*377	350*312*457
	Volume	9.2L	12.8L
	Shelf Number	2	
	Load Per Rack	5kg	
	Shelf Space	35mm	
	Supply(50/60HZ) Current rating	AC220V/0.36A	AC220V/0.36A
	NW/GW (kg)	8/10	12/14
Optional Accessories		Vehicular/DC12V/AC110V/AC220VSupply	

## 4. The panel indication




Figure 1

### Key defines

【Set】 : Set key, in the main screen state, click this key to enter the temperature and time target value Setting state, long press this key for 3 seconds to enter the internal parameter Setting state.

【 】 : Shift / Auto-tuning, in the Setting state, click this key to change the Setting value. In the main screen state, long press this key for 6 seconds to temperature auto-tuning selection state.

【 】 : Decrease / rerun key. In the Setting state, click or long press this key to decrease the Setting value. In the main screen state, long press this key for 3 seconds to restart the run.

【 】 : Increase / lock screen key. In the Setting state, click or long press this key to increase the Setting value. In the main screen state, click this key to lock or unlock the screen.

### LED indicator Defines

1. 【AT/F】 indicator :The lamp will be on when the temperature unit is degree Fahrenheit .The lamp will flash in auto-tuning, it will flash. In other states, it will be off.
2. 【TIM】 indicator: The lamp will be on when there is a timing Setting,it will flash in reservation timing, it will be off when no timing function.
3. 【OUT】 indicator :The lamp will be on when there is heating output , otherwise it will be off.
4. 【LOC】 indicator : The lamp will be on when the screen is locked, otherwise it will be off.
5. 【SIN】 indicator : Invalid reservation
6. 【ALM】 indicator: The lamp will be on when there is temperature deviation alarm or abnormal temperature measurement.It will flash when there is temperature deviation alarm. Under normal condition, it will be off.

# 5. Operations and usages

## 1. Controller power on display

After all the display are on for about 3 seconds, PV area displays SV displays version number for about 1 second and then enters the normal display state.

## 2. Reference and Setting of temperature and time

### 1) No-timing function:

In the main screen state, click the **【Set】** to enter the temperature Setting state, the PV area displays prompt SP, and the SV area displays the temperature Setting value, which can be modified to the required Setting value through the **【shift】** , **【increase】** , **【decrease】** , then click the **【Set】** to exit the Setting state, and the Setting value will be saved automatically.

### Timing function:

In the main screen state, click the **【Set】** to enter the temperature Setting state, the PV area displays the prompt SP, the SV area displays the temperature Setting value, and the modification method is the same as above; then click the **【Set】** to enter the time Setting state, the PV area displays the prompt ST, TIME area displays the time Setting value; then click **【Set】** to exit the Setting state, and the Setting value will be saved automatically.

When the Setting time is "0", it means continuous operation. When the Setting time is not "0", before the timing starts, if the timing direction is count-down, the TIME area will display the timing time; if the timing is count-up, the TIME area will display "0". When the timing starts, "indicator" will flash. When the time is up, the operation will end. The TIME area will display End, and the buzzer will beep for EST seconds (see 7. Parameter TABLE-1). At this time, long press the **【decrease】** for 3 seconds, the operation can be restarted.

## 3.Reservation function(see7.Parameter TABLE-6)

When an reservation time is Set, heating operation is prohibited.

PC-D9000 type: In reservation timing,A indicator flashes, and the count-down TIME area displays the reservation running time.

PC-E9000: In reservation timing,TIM indicator flashes, and the count-down TIME area displays the reservation running time.

## Abnormal temperature measurement alarm

If the PV area displays "----", it means that the temperature sensor is faulty or the temperature exceeds the measuring range or the controller itself is faulty. The controller will automatically disconnect the heating output, the buzzer will sound continuously and the alarm light will be on. Please check the temperature sensor and its wiring carefully.

## 5.Deviation over temperature alarm (see 7. Parameter TABLE-1)

When the upper deviation over temperature alarm occurs in process, the buzzer beeps, the alarm light is continuously on, and the heating output is disconnected. When the lower deviation over temperature, the alarm will occur and flash. If the over temperature alarm is generated due to changing the temperature Setting value, the alarm light will be on, but the buzzer will not sound.

## 6. Lock screen function.

Three screen locking modes are provided. See [7. Parameter TABLE-1] for details.

Password unlocking: In the lock screen state, click the **【increase】** , the input password prompt PA is displayed in PV area, and the password is displayed in SV area. After entering the correct password, click the **【Set】** to unlock.

## 7. When the buzzer sounds, press any keys to silence.

## Auto-tuning system

When the temperature control effect is not ideal, the system can be auto-tuning. There will be a large

overshoot in the process of auto-tuning. Please take this factor into consideration before system auto-tuning.

In the running state and the main screen state, long press the **【shift】** for 6 seconds to enter the system auto-tuning selection state. The PV area displays the auto-tuning prompt AT, and the SV area displays "0". You can click the **【increase】** or **【decrease】** to select the display "1", and then click the **【Set】** to enter the system auto-tuning state. The AT light flashes. After the auto-tuning is completed, the AT light stops flashing. The controller will get a better set of PID parameters and save them automatically. In the process of system auto-tuning, long press the **【shift】** for 6 seconds to stop the auto-tuning program.

In the process of system auto-tuning, if there is an over temperature alarm of upper deviation, the alarm light will not be on and the buzzer will not sound, but the alarm relay will be automatically disconnected. In the process of system auto-tuning, the **【Set】** is invalid.

## 6.Seven The internal parameters of the temperature are seen and Set.

In the main screen state, long press the **【Set】** for 3 seconds, the password prompt LC will be displayed in PV area, and the password will be displayed in SV area. Modify the required password through **【increase】** , **【decrease】** and **【shift】** , and then click the **【Set】** . If the password is incorrect, the instrument will automatically return to the main screen state. If the password is correct, enter the internal parameter setting state, and then click the **【Set】** to modify each parameter in turn. In this process, long press the **【Set】** for 3 seconds to exit this state, and the parameter value will be saved automatically. See the table below for details:

Parameter Table

The Indicator	Parameter Name	Description of the parameter function	(Range) Initial value
Lc	Password.	Lc=3,parameter values can be viewed and modified	0
ALH	Upper Deviation Over-temperature Alarm	PV>SP+ALH, over-temperature alarm of upper deviation	(0~100.0°C) 20.0
ALL	Lower Deviation Over-temperature Alarm	PV<SP-ALL,over-temperature alarm of upper deviation Description:ALL=0,the lower deviation alarm is invalid	(0~100.0°C) 0
Pb	Temperature Measurement Deviation Correction	Used to correct errors in temperature measurement. Pb = Actual temperature-PV	(-50.0~50.0°C) 0

PL	Temperature Measurement Slope Correction	It is commonly used to correct errors arising from high temperature measurement. PL = 1000 * (Actual temperature-PV)÷ PV Description: In Parameter 【TABLE - 4】 ,En = 1 This feature is invalid.	(-999~999) 0
ndT	Timing Mode	0:No-timing; 1:Constant temperature timing; 2: Run timing.	(0~2) 1
Tdn	Timing Direction.	0:Count-up; 1:Count-down	(0~1) 0
Hn	Time Unit.	0:Minute; 1:Hour	(0~1) 0
SPd	Constant Temperature Deviation	SP-SP d ≤PV≤SP+SP d, Enter a constant temperature state.	(0.1~50.0°C) 0.5
EST	End Timing Prompt Time	When the timing is over, the buzzer will prompt the time. Note: EST = 9999, indicates a permanent prompt.	(0~9999s) 60
EH	End Timing Constant Temperature Controller	0: Turn off the heating output after timing; 1: Keep constant temperature controlling after timing	(0~1) 0
LF	Lock Screen Function	0: Lockless screen function; 1: Lock screen function, unlock without password. 2: Lock screen function, need password to unlocked.	(0~2) 0
LdT	Lock Screen Delay	In the main screen state, if no key is pressed in the delay LDT time, the controller will automatically lock the screen. Description: LDT = 600, the delay screen locking function is invalid	(10~600s) 30
PAd	Unlock Password	The password must be entered to unlock it.	(0~9999) 1
Add	Mail Address	Local Address Description: PC-E9000 has no communication function.	(1~32) 1

Table 2

The Indicator	Name	Description of the parameter function	(Range) Initial value
Lc	Password	Lc=567,parameter values can be viewed and modified	0
rST	Factory Reset	0:Cancel; 1:Conform.	(0~1) 0

Table 3



**Biolab Scientific Ltd.**

Trillium Executive Center, East Tower, 675 Cochrane Dr, Markham, Ontario L3R 0B8, Canada  
Email: [info@biolabscientific.com](mailto:info@biolabscientific.com) | Website: [www.biolabscientific.com](http://www.biolabscientific.com)