



GENERAL PURPOSE INCUBATOR

BIGP-613

INDEX

1. Application	2
2. Performance	2
3. Technical parameters	3
4. Components	3
5. Equipment installation	4
6. Installation	5
7. Preparation before Operation	6
8. Panel instruction	6
9. Operation and usage	8
10. Inner technical parameters	9
Parameter-1	9
Temperature parameter-2	10
Humidity parameter -3	11
Compressor parameter -4	11
parameter -5	12
11. Specification	13
12. Wiring layout	14
BIGP-613 -Series	15

1. Application

• BIGP-613 constant temperature and humidity chamber is thermostatic equipment with heating, cooling and humidification function, highly precise and advanced. Widely used in plant cultivation, breeding test, bacteria, mold, microbial cultivation & preservation, BOD determination and so on. Which is also used in biological genetic engineering, medical treatment, health and epidemic prevention, medical test, agriculture and animal husbandry, aquatic and other scientific research institutions.

2. Performance


Constant temperature and humidity transfers actual temperature and humidity detected from temp. sensor and humidity sensor into signal. Through microcomputer control to heater towards required temperature and humidity.

3. Technical parameters

1. volume: 150L.250L.400L
2. Temp range : 0~65°C;(with humidity5~50°C);
3. Temp fluctuation range : $\pm 0.5^{\circ}\text{C}$ (10°C~40°C);
4. Temp uniform range : $\pm 1^{\circ}\text{C}$ (10°C~40°C);
5. Humidity range : 40-95%RH(10°C~40°C);
6. Humidity fluctuation : $\pm 2\%$;
7. Power voltage : 220V/50Hz;
8. Input power: 1080W(150L) 1100W(250L) 1350W(400L);
9. Working ambient : ambient temp 10~30°C relative humidity70% below ;
0. refrigeration: R134;
1. Equipment class: class I

Notice : this equipment has low temperature auto-defrost function, it is normal that there is fluctuation when low temperature auto-defrost

4. Components



Structure

5. Equipment installation

In order to make sure the equipment can run normally, please place equipment as following:

Attention: ambient temperature 10~30°C ;relative humidity less than 70%

1. Avoid exposure to the sunlight.

Do not place it in direct sunlight, or it won't reach predicted performance

2. An efficient vent place

If you operate this equipment in a narrow and concealed room, it may lead to over-heating and malfunctioning. Minimum safe distance between equipment and wall is 10CM

d) Keep away from heat source

Don't install the equipment near heating source. External excess heat will affect performance of the equipment and may cause malfunctioning

e) Flat and firm ground

Make sure to install it in flat and firm ground. Uneven surface or leaning installation may damage equipment or injure people. Proper installation can avoid shaking and noise

f) Avoid humid place

Install the equipment in a place where humidity is less than 70%. Otherwise it may cause short-circuit or electric shock. Warning

Do not place this equipment outdoors. If it exposed in the rain, it may cause short-circuit and electric shock.

Do not place equipment in humid environment or a place with dripping water. Otherwise it may cause short-circuit or electric shock

- Avoid place with flammable or corrosive gas.

Do not place equipment near flammable materials and volatile substance. Otherwise it may cause explosion or fire. Do not place equipment in the place where has acidic and corrosive gas, or corrosion will cause short-circuit, electric shock or equipment damage.

6. Installation

1. Unpacking

Remove packing materials ,open the door for ventilation. Please use neutral detergent to clean if the shell and panel is dirty. then wipe with wet cloth and at last with dry and clean cloth

2. level equipment

Fix equipment with the front brake-wheel after installation in case equipment moves

3 Earthing

Warning

Please use power socket that has protective conductor terminal in case of electric shock. If it is not connected, has to install protective conductor terminal by licensed technician.

Do not connect protective conductor terminal through gas, water pipe, telephone line or lighting arrester which will cause electric shock.

4. Idle equipment

Before setting equipment aside , empty water in the humidifier and remove internal, moisture thoroughly. Be sure the inner chamber is dry and cool before closing the door .

5. Move equipment

Before moving equipment ,empty water in the humidifier .or it will cause creepage or electric shock because of overflow water or splashed water

7. Preparation before Operation

When equipment running in the first time, please operate as below:

1.Take out the shelves or other accessories

2.Clean the inner wall with gauze which is soaked by alcohol and then use dry cloth to wipe-dry


3.Put the shelves into inner chamber according to your experiment of requirement

4.Put water tank on the top of equipment before using ,please connect water pipe with water inlet and overflow outlet which in the left of equipment (refer to component picture) ,and put storage water tank under the overflow pipe and water outlet for spare use

5.Pour enough pure water into water tank

Notice : don't use NaCl or other Halide solution to clean equipment ,or it will cause rust

8. Panel instruction



Symbol definition

- T1: appointment: its twinkling means the controller enter into appointment mode, meanwhile, the (2) area displays appointment time (count down).
- T2: heat: its lightening means heater working.
- T3: refrigeration: its lightening means air compressor working.
- T4: humidity: its lightening means humidifier working.
- T5: daytime: its lightening means the machine is in daytime mode.
- T6: night: its lightening means the machine is in night mode.
- T7: timer: its twinkling means the timer working, meanwhile, the (2) area displays setting time(count down).
- T8: lack of water: its lightening means lack of water, its twinkling means low-level water alarm.
- T9: door open: its lightening means the door is open
- T10: alarm: its lightening means temperature or humidity alarm; its twinkling means low-temperature or high-temperature protection.
- T11: screen lock: its lightening means screen is locked, one can not change any setting value before unlock it.
- T12: watering: its lightening means water pump working.
- T13: defrosting: its lightening means the defrosting system working.
- T14: valve: its lightening means valve working.
- T15: illumination/sterilization: its lightening means lamp working, its twinkling means UV lamp working.

Display window

- (1) Area: cycle/segment
- (2) Area: timer or setting time
- (3) Area: current temperature value
- (4) Area: temperature setting value
- (5) Area: current humidity value
- (6) Area: humidity setting value
- (7) Area: illumination or heating output power

Button definition

- Screen lock: in normal mode, one can press on this button for 2 seconds to lock or unlock the screen.
- Light: in normal mode, one can click on this button to switch on/off the lamp.

Set: in normal mode, one can click on this button to set value of temperature, humidity, illumination and others; or press on this button for 3 seconds to enter into inner parameters.

Shift: in setting mode, one can click on this button to shift digit position; in normal mode, one can click on this button to shift daytime or night mode; in programmable mode, one can click on this button to inquire cycles and segments.

Decrease/defrost: in setting mode, one can click on this button to decrease setting value; in normal mode, one can press on this button for several seconds to activate defrosting function.

Increase: in setting mode, one can click on this button to increase setting value

R/S: in normal mode, one can click or press on this button to start or stop the controller running.

9. Operation and usage

1. After power on, (3) area displays "PS", (5) area displays "V01", the buzzer beeps, and then ,after 2 seconds, the controller will enter into normal mode.

2. Setting values: after clicking on set button in normal mode, symbols "TIME"and"SV" twinkle, one can modify the setting value (digit position twinkling), by shift, decrease, increase buttons, and one can shift to next group value by another clicking on set button. After modification, one can press on set button for 1 seconds to quit setting mode, the setting value will be saved automatically.

In programmable mode, segment value position twinkles after clicking on the set button. In this time, one can modify the segment number by decrease or increase button, and inquire setting value of time, humidity, temperature, and illumination in every segment.

In day/night mode, after clicking on set button, "DAY"symbol will twinkle, then, one can choose daytime or night mode by decrease or increase button, after another click on set button, one can inquire and modify every value of current mode, by increase and decrease buttons.

3. Setting of cycles and segments: in programmable mode or day/night mode, when the controller is in stop situation, after pressing on "set" button for 3 seconds, the (1) area displays "Lc", the (2) area displays "0", users can adjust the password to 3 by increase/decrease buttons, so that the controller enters cycle and segment setting mode. PRO---total program number, CYC---total cycle number.

4. fault reminder:

Temperature alarm: symbol"°C"flashes quickly when upper deviation occurs, symbol"°C"flashes slowly when lower deviation occurs;

Humidity alarm: symbol"%RH"flashes quickly when upper deviation occurs, symbol"%RH"flashes slowly when lower deviation occurs;

If the (3) area displays "---",user should check the sensor and controller.

10. Inner technical parameters

In normal mode, press on set button for 3 seconds, the (1) area will display "Lc", users can input right code and click on the set button one more time to enter different inner parameters. After adjusting the value of parameters, please do remember to press on the set button for another 3 seconds to quit setting mode. the value adjusted will be saved automatically.

Parameter-1

symbol	name	function	(range) factory value
Lc	password	when "Lc=9", this parameter group can be inquired and adjusted.	0
U1	Running mode	0: constant value mode; 1: day/night mode, 99 cycles; 2: program mode, 1~30 segments, 0~99 cycles	(0~2) 0
U2	Power down protection	0: no operation; 1: begin with the first segment; 2: restart from the power down time	(0~2) 0
U3	Timer adjust	Modification value= 【display value (s) -real value (S)】 *10 real value (m)。	(-999~999) 0
U4	Timing unit	1: minute 0~9999; 2: hour 0~9999	(1~2) 1
U5	Timing temperature point	When U5= display temperature-setting temperature, timer starts to work	(0~10.0°C) 0
U6	Timing humidity point	When U6= display temperature-setting temperature, timer starts to work	(0~50.0%) 0
U7	【R/S】 time	Press on the 【R/S】 for U7 time to run/stop	(0~10s) 0
U8	Lock screen time	Lock screen time, 0 means unlock	(0~300s) 0
U9	Reminder time (stop)	The buzzer beeps for U9 seconds when running stop. 0 means buzzer beeps continuously	(0~300s) 0
UA	Illumination time	Illumination time, 0 means manual operation	(0~9999min) 0
Ub	address	Communication address	(1~16) 1

Temperature parameter-2

symbol	name	function	(range) factory value
Lc	password	when“Lc=103”,this parameter group can be inquired and adjusted.	0
TH	Temperature upper deviation alarm	when“display value>set value+TH”, upper alarm occurs, heating and humidity cut down User can click on any button to stop buzzer	(0~20.0°C) 5.0
TL	Temperature lower deviation alarm	when“display value<set value+TH”, lower alarm occurs, heating and humidity cut down User can click on any button to stop buzzer	(-50.0~0°C) 0
Tb	Zero adjust(low temperature)	$Tb = \text{real temperature} - \text{display temperature}$	(-99.9~99.9) 0
TA	Full adjust(high temperature)	$TA = 1000 * (\text{real temperature} - \text{display temperature}) \div \text{display temperature}$	(-999~999) 0
TP	Proportional band	Adjustment of proportional function.	(0.1~50.0) 8.0
TI	Integration time	Adjustment of integration function	(1~2000s) 500
TD	Differential time	Adjustment of differential function.	(0~2000s) 200
TT	Heat period	Heating control period	(1~60s) 5
Tc	Low temperature cutoff	Heating cutoff point.	(-2.0~0°C) -0.5
To	Heat power	Heating max power percentage	(0~100%) 100

Humidity parameter -3

symbol	name	function	range factory value
Lc	password	when“Lc=203”,this parameter group can be inquired and adjusted.	0
HH	Humidity upper deviation alarm	when“display value>set value+TH”, upper alarm occurs, heating and humidity cut down User can click on any button to stop buzzer	(0~50.0%) 20.0
HL	Humidity lower deviation alarm	when“display value<set value+TH”, lower alarm occurs, heating and humidity cut down User can click on any button to stop buzzer	(-50.0~0%) 0
Hb	Zero adjust(low humidity)	$Tb = \text{real humidity} - \text{display humidity}$	(-99.9~99.9%) 0

HA	Full adjust(high humidity)	$TA = 1000 * (\text{real humidity} - \text{display humidity}) \div \text{display humidity}$	(-999~999) 0
HP	Proportional band	Adjustment of proportional function.	(0.0~90.0) 10.0
HI	Integration time	Adjustment of integration function	(1~999s) 200
Hd	Differential time	Adjustment of differential function.	(0~999s) 30
HT	Heat period	Heating control period	(0~60s) 5
Hc	Low temperature cutoff	humidity cutoff point.	(-50.0~50.0%) 0.0
Ho	humidity power	Humidity max power percentage	(0~100%) 100

Compressor parameter -4

symbol	name	function	(range) factory value
Lc	password	when“Lc=109”,this parameter group can be inquired and adjusted.	0
C1	Forbidden compressor	when“temp.measured value \geq C1”, the compressor must not work.	(0~100.0%) 80.0
C2	Not start compressor	when“temp.setting value \geq C2”, Start the compressor only once when the temperature measuredt value is higher than the temperature setting value.	(0~100.0%) 42.0
C3	Constant temp.open point	when“temp.setting value \leq C3”, compressor works in balance mode	(-15~100°C) 0.0
C4	Costant humi open point	when“humi.setting value \leq C4”, compressor works in balance mode.	(0~100%) 10
C5	Working mode		(0~3) 3
C6	Compressor start delay		(0~600s) 180
C7	Defrost mode		(0~2) 0
C8	Defrost interval 1		(0~9999min) 0
C9	Defrost interval 2		(0~9999min) 0
CA	Defrost interval 3		(0~9999min) 0
Cb	Defrost time 1		(0~200s) 0
Cc	Defrost time 2		(0~200s) 0

Cd	Defrost time 3		(0~200s) 0
CE	Solenoid valve function		(-2~1) -2
CF	Solenoid valve start		(0~50.0°C) 0

parameter -5

symbol	name	Function	(range) factory value
Lc	password	"Lc=209" this parameter group can be inquired and adjusted.	0
P1	Illumination control	0: no illumination 1: 3 levels 2: 4 levels 3: 5 levels 4: 6 levels 5: 10 levels	(0~5) 4
P2	Humidity set	0: no humidity; 1: humidity display only; 2: humidity can be controlled.	(0~2) 2


appointing set -5

symbol	name	function	(range) factory value
Lc	password	When "Lc=36" this parameter group can be inquired and adjusted.	0
AP	Appointing set	0: shut off appointing fuction; 1: start appointing fuction	(0~1) 0
T_	Appointing time	When AP=1, the timer can be set.	(0~9999min) 0

11. Specification

Name	BIGP-613 series constant climate chamber
Model	BIGP-613
Exterior Dimension	745×930×1700
Interior Dimension	601×639×1052
Effective volume	392L
Shell	Cold-roll steel sheets with powder coat treatment
Inner shell	SUS304 mirror stainless steel
Door	With heating preservation design
inner door	Tempered glass (5mm)
Shelf	Carbon steel with chromeplate
Heating preservation system	Polystyrene foam
Cooling system	R134a(without fluorine), Green, environmental protection, energy saving
Heating system	Use finned high efficient heating tube
Fan	Axial flow fan
Humidity System	Use electric heating to control humidify stable
Temp. sensor	Sumsung Temp. sensor PT100
Humidity sensor	Cybersen humidity sensor
Display	LCD(Liquid Crystal Display),China Display
Warning system	Temp. & humidity upper limit warning with screen prompt; Temp. & humidity sensor fault warning with screen prompt
Weight	145kg
Optional Accessories	Switch port ,Portable printer

12. Wiring layout



BIGP-613 -Series

constant temperature and humidity chamber
Packing List

No	Name	Quantity	Note
1	product	1	
2	manual	1	
3	shelf	3(150L) 4(250L) 4(400L)	
4	storage water tank	1	
5	water tank	1	
6	Inlet pipe	1	
7	outlet pipe	1	



Biolab Scientific Ltd.

3660 Midland Avenue, Suite 300, Toronto, Ontario M1V 0B8, Canada
Email: info@biolabscientific.com | Website: www.biolabscientific.com