

OPERATING MANUAL



CONDUCTIVITY METER

BMET-301





www.biolabscientific.com

INDEX

2
2
2
3
1
1
5
5
7
7
3
9
10
11
14
15
15
15
223445577891111

1 Introduction

1.1 Introduction

BMET-301 Conductivity Meter can measure conductivity in water solution, and can be widely used in universities, environmental protection, medicine, food, sanitation, geological prospecting, metallurgy, ocean exploration.

1) General Features

- LCD display screen, 6.0 inches.
- Cell constant is settable.
- Manual temperature compensation ensures accurate results.
- IP54 protection.

1.2 Technical Specification

Model		BMET-301	
	Range	0.00µS/cm~100.0 mS/cm	
	Resolution	0.01 μ S/cm, automatic switching according to the range	
Conductivity	Accuracy	± 1.5%(FS)	
	Repeatability	0.5%(FS)	
	Measurement Accuracy	±2.0%(FS)	
	Measurement Repeatability	1.0%(FS)	
Temperature Range		Manual (0.0~60.0)°C	
Work environment		Ambient temperature: (0 \sim 40)°C Relative humidity: not more than 85%	
Dimensions (L×B×H), weight (kg).		200mm×160mm×63mm, 0.6kg	
Power supply		AC Adapter, 100-240V AC input, DC 9V output	

Table 1-1 Instrument Specifications

1.3 Function Introduction

Table 1-2 F	unction	Introduction
-------------	---------	--------------

Function		Explanation
	Backlight adjustment	•
	Reset settings	•
Basic Function	Power failure protection	•
	Automatic shutdown	•
	Protection	IP54

Reading Function	Reading Mode	continuous-read
	Conductivity	•
Measurement	Cell constant set	•
	Manual temperature compensation	(0.0°C~60.0°C)
Temperature Function	Temperature Unit	°C

2 Safety Notices

Please read the entire contents of this manual carefully before use, and please keep this manual properly. The user MUST use the instrument following this manual to avoid damage to the user and equipment.

Before using the meter, READ the following notes:

- DO NOT disassemble the device for inspection or repair.

- To prevent electric shock or damage to the device, do not place cables and connectors in any liquid, wet or corrosive environment.

- Please use the defaulted power adapter, Do not use it if the power cord is damaged (the wire is exposed or broken).

- Do not use in flammable and explosive environments.

- Do not use if the user finds any abnormalities such as damage or deformation of the device.

The following identifier will be used in this manual.

3 Terms Explanation

- Cell Constant: Also known as the conductivity cell constant. The ratio of the distance to the area of the electrode sheet, expressed in cm-1. Usually, there are conductance electrodes with several cell constants such as 0.01, 0.1, 1.0, 10, etc. The conductance electrode with a cell constant of 1.0 is the most used one and has a wide measurement range.

- Temperature Coefficient: The change in conductivity caused by a 1°C change in temperature is usually expressed in %/°C, and the default is 0.02, which is 2.00%/°C.

4 Overview and Installation

4.1 Overview



Fig. 4-1 Overview-Front View



Fig.4-2 Overview- Back View



12 5-pin aviation connectors13 Electrode protection cap14 Conductivity electrode

Fig. 4-3 Electrodes and connectors Table 4-1 Connector Specifications

Electrode type	Connector specifications
Conductivity electrode	5-pin aviation

4.2 Instrument Installation

4.2.1 Electrode Stand Installation

1) Screw the electrode stem into the screw hole of the insert plate.

2) Insert the round hole at the back of the electrode fixing clip into the electrode stem, adjust the height, and tighten the fixing screw.



Fig. 4-4 Electrode Stand Installation

4.2.2 Electrodes Connection

Push the conductivity electrode into the electrode holder. Remove the protector cap of the conductivity electrode. Connect the conductivity electrode into the right socket.

5 Instrument Operation

5.1 Screen Icons

The meter has 6.0 inches high resolution LCD display screen. The User interface has the menu, status, result. The menu has measurement and setting. The status shows the reading mode, reading prompts and auto shutdown etc. The result shows the conductivity, unit, temperature, cell constant type etc.



Fig. 5-1 Screen icons explanation Table 5-1 Symbol Explanation

No.	Symbol	Explanation	Note
1	CR	continuous-read	Continuous Reading
2		Reading state	When all four sections are lit up, it shows a stable status
3	Ð	Automatic shutdown	Automatic shutdown has been set
4	OK?	Confirm the option	Flashing Display when Need to Confirm
5	μS/cm	Conductivity Unit	Unit: μS/cm
6	mS/cm	Conductivity Unit	Unit: mS/cm
7	Sec	Time Unit	Unit: Sec
No.	Symbol	Explanation	Note
8	°C	Temperature Unit	Unit: °C
9	MTC	Manual temperature compensation	
10	Const	Cell Constant	
11	Туре	Electrode Type	
12	ł	Measurement	
13	\$	Setup	

5.2 Key Function

۳ 26	8.0 1	uS/cm
▲ Setting/▼	Const	Enter Cancel
	U	

Fig. 5-2 The Screen and the Key Table 5-2 Key Function Explanation

No.	Кеу	Explanation	Note
1	6	Power Key	Switch on the meter by press and release the key. Switch off the meter by press and hold the key for more than 3 seconds and release. Backlight adjustment key when Switch on the meter.
2		Up	Increase the number in setting.
3	Setting/▼	Setting/Down	View the setting. Decrease the number in setting.
4	Const	Constant	Cell constant settings.
5	Enter	Enter	Confirm.
6	Cancel	Cancel	Give up.

5.3 Instrument Settings

5.3.1 Switch On/Off

Connect the power adapter, and press and release to switch on the meter. The startup screen shows software version and other related information. After the self-test program, the screen turns to the homepage and the meter are ready to measure. Press and hold the key for more than 3 seconds and release to shut down.

Table 5-3 Switch On/Off Interface Explanation

No	Displa y	Explanation
1	U11	Switch On, Software Version

2 OFF Switch Off

5.3.2 Instrument Settings

The meter has the parameter setting, such as Temperature Settings, Automatic shutdown settings, Reset settings. Press the "Setting/ ∇ ", the meter shows the setting symbol, SEL and No. Press the up and down to adjust the parameter and select the Enter to select.



Fig. 5-3 Instrument Settings Table 5-4 Instrument Settings

No.	Explanation	Note
1	Temperature Settings	Flashing display °C
2	Automatic shutdown settings	Flashing display "APD"(Auto Power Down)
3	Reset settings	Flashing display "rSt" (Reset)and "dFt" (Default)

5.3.2.1 Temperature Settings

The meter supports manual temperature compensation. Measure the test solution temperature with the temperature meter. Press the "Settings/ ∇ " to select the "Temperature Settings", adjust the temperature as the real temperature.



Fig. 5-4 Temperature Settings

5.3.2.2 Automatic shutdown settings

The meter provides auto shutdown function. When the meter is not using and set the auto shutdown, the meter switches off automatically. There are six options: off, 300Sec, 600Sec, 1200Sec, 1800Sec, and 3600Sec.

5.3.2.3 Reset settings

When the meter is not working. Users can reset the meter from the default's backup. The default setting includes constant type as 1.0, Cell constant as 1.000, refer temperature as 25.0°C, automatic shutdown as close etc.



Fig. 5-5 Reset settings

Table 5-5 Reset settings Explanation

No.	Symbol	Note
1	rSt	Reset
2	dFt	Default
3	OK?	Flashing display

5.4 Calibration

5.4.1 Calibration Preparation

In common, there are two type calibrations. one is entering the cell constant value directly; the other is calibrating the conductance electrode with standard conductivity standard solution.

There are many conductance electrodes in order to suit for different measurement range. According to the material, conductive electrode is divided into platinum black electrode and bright electrode. Usually, there are conductance electrodes with several cell constants such as 0.01, 0.1, 1.0, 10, etc. The conductance electrode with a cell constant of 1.0 is the most used one and has a wide measurement range.

It is needed to choose the suitable conductance electrode according to the sample properties, such as the conductivity range as recommend table.

Table 5-6 Conductivity Range and Cell Constant recommend

Cell constant cm -1	Conductivity range µS/cm	
0.01	0∼2.000 µS/cm	
0.1	0.2∼20.00 µS/cm	
1	2 μ S/cm \sim 100.0 mS/cm	

5.4.2 Cell Constant Settings

Users need to enter the cell constant value on the label of conductance electrode for accurate measurement. The defaulted conductivity cell constant is 1.

Cell constant settings process is as follows:

- In the measurement status, press "Const", it shows the cell constant and constant type.
- Adjust the constant type by press the "Setting/▼".
- Adjust the cell constant by press the " \blacktriangle " and "Setting/ \bigtriangledown ".
- Press "Enter" to save the constant.



Fig. 5-8 Constant Type is 0.1, Cell constant is 0.0998

5.4.3 Calibration with standard

In general, conductivity electrodes need few calibrations. When the user gets an unexpected result, an electrode calibration is considerable.

Usually, single standard solution is required for calibration. The standard solution needs close to the sample. After calibration, user could calculate the cell constant and set the cell constant.

For conductivity electrodes with different cell constants, it is recommended to use the following conductivity standard solutions for calibration.

Table 5-7 KCl standards to electrode cell constants

Cell constant (cm -1).	0.1	1	10
KCl solution Concentration (mol/L).	0.001	0.01 or 0.1	0.1 or 1

Table 5-8 Approximate concentrations of KCI solutions and their conductivity values relationship.

T (°C)	84µS/cm	1413µS/cm	12.88mS/cm
5	53.02	896	8.22
10	60.34	1020	9.33

15	67.61	1147	10.48
20	75.80	1278	11.67
25	84.00	1413	12.88
30	92,19	1552	14.12
35	100.92	1696	15.39

The manual calibration process is as follows:

- Place a standard conductivity (e.g., 1413 μ S/cm conductivity solution) solution in a thermostatic bath, and set the temperature to (25.0 \pm 0.1) °C.

- Rinse the conductance electrode with DI water, dry out and place it into a standard solution.

- When the conductivity and temperature reading are stable, record the conductivity value Ct ((eg.1420 μ S/cm, 25.0°C).

- Get the standard conductivity value Cs (e.g.,1413µS/cm, 25.0°C) according to the table.

- Calculate the cell constant, k=Cs/Ct.
- In the measurement status, press "Const", it shows the cell constant and constant type.
- Adjust the constant type by press the "Setting/▼".
- Adjust the cell constant by press the " \blacktriangle " and "Setting/ \bigtriangledown ".

- Press "Enter" to save the constant.

5.5 Measurement

5.5.1 Measurement Preparation

Before measurement, the user should understand the properties and attributes of the substance (sample) to be measured, the method of routine testing, the basic operation and application of the instrument, and the use and maintenance of conventional electrodes.

The user needs to prepare the sample, the standard solution that needs to re-calibrate the electrode, etc. 5.5.2 Measurement

The measurement process is as follows:

- Rinse the electrode with DI water. Put the measurement end of the electrode into the sample solution.

- Measure the test solution temperature with the temperature meter. Press the "Settings/ ∇ " to select the "Temperature setting", adjust the temperature as the real temperature.

- When the reading is stable, end the measurement and save the results.

- After measurement, switch off the meter, and store the probe referring to the electrode instruction manual.



Fig. 5-9 Measurement Results

6 Maintenance/Troubleshooting

6.1 Maintenance

The correct use and maintenance of the instrument can ensure the accurate and reliable performance of the instrument. Additionally, exposure to chemicals or harsh use environments can affect performance.

- If the meter is not used for a long time, please disconnect the power supply.

- The electrode socket of the instrument must be kept clean and dry, and should not be in contact with acid, alkali, and salt solutions.

- Keep the meter and accessories clean and away from acids, alkalis, and any corrosive solutions/gases.
- Users can clean the meter surface with clean waters and detergent.
- When the meter is transported, please follow the instructions:
- please remove all connected cables.
- Please use original packaging in the long distance transport to avoid damage.

6.2 Electrodes Maintenance

Before using the electrode, you should read the electrode manual carefully to know the type, structure and application scope of the electrode.

For more detailed information, please refer to the electrode instruction manual.



Biolab Scientific Ltd. 3660 Midland Avenue, Suite 300, Toronto, Ontario M1V 0B8, Canada Email: info@biolabscientific.com | Website: www.biolabscientific.com